

# GG PLUS

3-Axis Stabilized Handheld Gimbal  
for Camera

## — Instructions —

Guilin Feiyu Technology Incorporated Company

User Manual    EN   V1.1


# Catalogue

[www.feiyu-tech.com](http://www.feiyu-tech.com)




1. G6 Plus Overview	1
2. Quick Start Guide	3
3. Balance the Gimbal	4
Balance Adjustment of the Pan Axis	4
Balance Adjustment of the Roll Axis	5
Balance Adjustment of the Tilt Axis	6
4. Basic Operation	7
Modes	7
Introduction of Display	7
Joystick - operation	8
Function Button - operation	8
Shutter Button - operation	8
Setting Button - operation	9
Switth Camera Modes	9
Setup Parameter	9
Horizontal Adjustment Button - operation	10
Trigger Button - operation	10
Multifunction Knob - Zooming control / Follow focus / Control 3 Axis	10
App - Download and Connecting	11
5. Advanced Operation	12
Manual Lock	12
Auto-rotation Mode	12
Connecting to Camera	13
Firmware Upgrade	13
Gimbal Initialization	14
6. Specifications	15

# 1. G6 Plus Overview




## Accessories



Micro USB Cable  
X1



26650 Li-ion Battery  
X1



Mount Adapter  
X1

## Introduction of Interface and screws

### ① Thumb Screw

Used for fixing the camera or mobile phone to the adjustment sliding plate

### ③ Micro USB Port

(1) Used for charging the gimbal (input 5V / 2A), the gimbal can be used while being charged, but it is not available for external power supply.

(2) Used for firmware upgrade (computer), please refer to the firmware upgrade operation steps for details.

Please stuff up this port by the dustproof plug when it is not in use.

### ② Adapter Thumb Screw


Used for fixing the adjustment sliding plate.

### ④ 1/4-20 Thread Mount


Used for expand other accessories, such as the tripod which built-in 1/4 inch screw, extension rod and so on

## Introduction of Display and Bottoms

### 1 Display



### 2 Joystick



### 3 Function Button [Refer to Page 8](#)

Long press	Power on / Power off
Single tap	Panning Mode / Lock Mode
Double tap	Follow mode
Triple tap	Rotate 180° in horizontal
Quadruple tap	Auto-rotation Mode
Five tap	Initialization

### 4 Shutter Button [Refer to Page 8](#)

After connecting the gimbal to camera via Feiyu On App, shutter button can control the camera for shooting.

[Please refer to the chapter "Connecting to camera" in page 13](#)

### 5 Setting Button [Refer to Page 9](#) (After connecting your camera)

Long press	Switch the interface for camera parameters
Single tap	Switch camera modes / main interface

[Please refer to the chapter "Connecting to camera" in page 13](#)

### 6 Horizontal Adjustment Button

You can control the horizon angle via the horizontal adjustment button.

[Refer to Page 10](#)

### 7 Trigger Button [Refer to Page 10](#)

Press and hold	Lock Mode
Double tap	Reset

### 8 Multifunction Knob [Refer to Page 10](#)

(1) Achieve the control to the focal length of camera, such as follow focus, zoom.

(2) Achieve the control to the angle of three axes of the gimbal

## Introduction of Axis and Knob

### 1 Tilt Axis

Take the camera lens as the base point, and control the camera lens to move upward or downward by tilt axis.

### 2 Tilt Axis Knob Ring

Used for fixing the sliding arm.

### 3 Roll Axis

Take the camera lens as the base point, and control the camera lens to tilt to the left or tilt to the right by roll axis.

### 4 Roll Axis Knob Ring

Used for fixing the cross arm.

### 5 Pan Axis

Take the camera lens as the base point, and control the camera lens to turn left or turn right by pan axis.

### 6 Pan Axis Knob Ring

Used for fixing the vertical arm.

## Introduction of Other Components

### 1 Sliding Arm

Used for adjusting the up and down centre-of-gravity position of tilt axis.

### 2 Adapter (Clamping plate)

Used for fixing the camera.

### 3 Adjustment Sliding Plate

Used for adjusting the front and back position of camera so as to adjust the front and back centre-of-gravity position of tilt axis

### 4 Cross Arm

Used for adjusting the centre-of-gravity position of roll axis.

### 5 Vertical Arm

Used for adjusting the centre-of-gravity position of pan axis.


### 6 Handle

Used for holding the gimbal by one hand.

## 2. Quick Start Guide

### 1 Install Battery

Remove the bottom cap, insert a 26650 battery and then tighten the cap.




Type	26650
Battery Capacity	5000mAh

### 2 Charging

**TIP** Please fully charge the battery before power on the gimbal for the first time.

Charging with Micro USB cable as shown below.




### 3 Put the Camera / Smartphone on


#### Put the Camera on

Correctly place the camera on the adjustment sliding plate, and tighten it with thumb screw in the middle sliding chute.

You can also take down the adjustment sliding plate from the adapter, install it to the bottom of the camera, and then install to the adapter.



If the camera doesn't have the 1/4-20 screw hole, please put the camera on mount adapter, which has 1/4-20 screw hole, and then mount it following above steps.



Camera Installation

#### Compatible for Reference





GoPro Sports Camera

#### Put the Smartphone on

Correctly place the smartphone on the smartphone adapter (Optional accessory), and tighten it with thumb screw in the middle sliding chute.

Available mobile phone width: 57~84mm



Smartphone installation

## 4 Balance the Gimbal

### NOTE

Unbalanced center of gravity can lead to a decrease in stability, even the camera cannot be balanced.

Power on the gimbal after the center of gravity of 3 axis is balanced.

Please refer to the follow chapter "Balance the Gimbal" for operation

## 5 Power on / off

### NOTE

- (1) Please mount the camera or smartphone before powering on the gimbal.
- (2) When the battery is low, please charge the gimbal.
- (3) When not in use, turn off the gimbal and then remove the battery.

### Power on / off

Long press the function button, the display will show **FJ** and release it when you hear the beep tone.


# 3. Balance the Gimbal ( Before power on )

## 1 Balance Adjustment of the Pan Axis


\* After adjustment, be sure to tighten the pan axis knob ring

### Steps

- (1) Hold the handle of gimbal, keep the handle parallel to the level ground.
- (2) **Loosen** the pan axis knob ring  
(Slightly loose until the vertical arm can be moved)
- (3) **Move and adjust the position of vertical arm**, until the vertical arm is parallel to the level ground
- (4) **Tighten** the pan axis knob ring



**After adjustment**  
Vertical arm is parallel to the level ground




## 2 Balance Adjustment of the Roll Axis





\* After adjustment, be sure to tighten the roll axis knob ring

### Steps

- (1) Stand the gimbal on level ground.
- (2) **Loosen** the roll axis knob ring  
(Slightly loose until the roll arm can be moved)
- (3) **Move and adjust the position of roll arm**, until the camera is parallel to the level ground.  
( Refer to lever principle )
- (4) **Tighten** the roll axis knob ring




**After adjustment**  
Camera is parallel  
to the level ground



### 3 Balance Adjustment of the Tilt Axis

#### Step 1


- (1) Stand the gimbal on level ground.
- (2) **Loosen** the tilt axis knob ring  
(Slightly loose until the sliding arm can be moved)
- (3) **Move the sliding arm to the lowest position.**



#### Step 2

\* After adjustment, be sure to tighten the thumb screw


- (1) **Loosen** the thumb screw on the bottom of the adapter(Clamping plate)  
(Slightly loose until the adjustment sliding plate can be moved)
- (2) **Move and adjust the position of adjustment sliding plate,**  
until the camera lens is parallel to the level
- (3) **Tighten** the thumb screw



#### Step 3

\* After adjustment, be sure to tighten the tilt axis knob ring

- (1) At any pitching angle, give an angle to the camera at random.
- (2) **Slightly adjust the position of sliding arm,** until it keeps still without shaking
- (3) **Tighten** the tilt axis knob ring



# 4. Basic Operation

## Modes

### Panning Mode (Default mode)

The roll and tilt direction are fixed, and the camera moves according to the left-right movements of the user's hand.

### Follow Mode


The roll direction is fixed, and the camera moves according to the left-right movements, up-down movements of the user's hand.

### Lock Mode

The orientation of the camera is fixed.

### Reset

Return to panning mode, three axes return to default position.



## Introduction of Display

Display icon	Mode / Status
HF	Panning Mode
AF	Follow Mode
LK	Lock Mode
⌘	Bluetooth is connected
⌘	Bluetooth is not connected
SET WIFI VIA APP	Prompt for users to open the App settings in order to connect via WiFi

Display icon	Mode / Status
🔋	Battery Level
📷	Camera photo shooting
📹	Camera video shooting
📶	WiFi is connected
📶	WiFi is not connected
📶	Camera is not connected

Please refer to the chapter "Connecting to camera" in page 13


## Joystick - operation

### Upward

- (1) Camera lens upward
- (2) Select the option above

### Move to left

- (1) Camera lens move to left
- (2) Select the option on the left
- (3) Cancel




### Move to right

- (1) Camera lens move to right
- (2) Select the option on the right
- (3) Confirm

### Downward


- (1) Camera lens downward
- (2) Select the option below



## Function Button - operation

Note: The firmware upgrade may occur manual operation function and the actual product features do not match. Please find the latest manual on the official website.

Single tap	Panning Mode / Lock Mode	Single tap to switch between panning mode and lock mode
Double tap	Follow mode	Under all follow, single tap to switch to locking mode
Triple tap	Rotate 180° in horizontal	Single tap to switch between panning mode and lock mode
Quadruple tap	Auto-rotation Mode	Enter auto-rotation mode Please refer to the chapter "Auto-rotation Mode" in page 12
Five tap	Initialization	Enter initialization Please refer to the chapter "Gimbal Initialization" in page 14




## Shutter Button - operation

After connecting the gimbal to camera/smartphone via Feiyu On/ Vicool App, single tap it to control the recording of the camera / smartphone.

Single tap	Shooting / Start shooting / Stop shooting
------------	---

On the main interface of the gimbal display

Please refer to the chapter "Connecting to camera" in page 13




## Setting Button - operation


After connecting the gimbal to camera via Feiyu On App, the setting button can switch the camera modes. Using the setting button and joystick to setup parameters.

Please refer to the chapter "Connecting to camera" in page 13

### Switch Camera Modes




### Setup Parameter



WB Setting	
AWB	Auto white balance
	Daylight
	Shade
	Cloudy
	Tungsten

ISO Setting	
	auto
	100
	125
	200
	400
	800
	1600
	3200
	6400
	12800

#### Using the joystick to set up parameters




Setting Parameters:

Joystick	Explanation
Move to right	To the right option / Confirm
Move to left	To the left option / Cancel
Move to up / down	Modify Parameters

## Horizontal Adjustment Button - operation

You can control the horizon angle via the horizontal adjustment button.

The control angle is  $-30^{\circ} \sim +30^{\circ}$




## Trigger Button - operation

Press and hold Quickly follow

In the panning mode or follow mode, press and hold the trigger button to enter quickly follow, release it to return previous mode

Double tap Reset

Return to panning mode, tilt, roll and pan axis return to initial level





## Multifunction Knob - Zooming control / Follow focus / Control 3 Axis

Single tap Switch adjustment option

Rotate Adjust by rotating

Long press Select the device you want to control



### Display

### Explanation

Zoom \*

Default

Zooming control

Camera supports zooming control

Follow Focus \*

Follow focus

Camera supports follow focus

\* After connecting your camera

Please refer to the chapter "Connecting to camera" in page 13

### Display

### Explanation

Pan Control

Control the pan axis rotation

Roll Control

Control the roll axis rotation

Tilt Control

Control the tilt axis rotation

## App - Download and Connecting

\* Requires iOS 9.0 or later, Android 5.0 or later

Using the **Feiyu ON** App when you **mount your camera** on the gimbal



iOS Version




Android Version

Using the **Vicool** App when you **mount your smartphone** on the gimbal



iOS Version



Android Version

Or search and download the "Feiyu ON" / "Vicool" App on the following application platform:



App Store



Google play

## Connecting App

Turn on the Bluetooth and run the App on smartphone, follow on the instructions to connect smartphone to gimbal via bluetooth. Take the Feiyu ON app connecting for example.



1



2



3


## 5. Advanced Operation

### Manual Lock

Camera can be manually positioned while in panning mode, follow mode or lock mode. Both the pan axis and tilt axis can be manually set up.

Manually move camera to desired position, and hold for half a second. New tilt and/or pan positions are automatically saved.

Take the tilt axis setting for example:



### Auto-rotation Mode

The G6 Plus gimbal can easily create constant speed movements in the auto-rotation mode. This mode can be used for recording both regular video and motion timelapse photography. For better performance, attach gimbal to the FeiyuTech tripod, or other tripod, to keep it completely still.

Set rotation speed in Feiyu ON App


Both the pan and tilt directions can be rotated.

Connect to the Feiyu ON App and select desired speed from the auto-rotation mode rate option in the settings menu.

G6 Plus Rotation Speed												
9s/ turn	18s/ turn	24s/ turn	30s/ turn	1min/ turn	2min/ turn	4min/ turn	8min/ turn	15min/ turn	30min/ turn	1h/ turn (Default)	4h/ turn	8h/ turn


#### (1) Enter auto-rotation mode

Enter auto-rotation mode by quadruple tapping the function button.




#### (2) Set rotation start position

Record the first position (rotation start position) by manually moving camera to desired position. Hold in position for half a second. Single tap the function button to record rotation start position.




#### (3) Set rotation end position

Record the second position (rotation end position) by manually moving camera to desired position. Hold in position for half a second. Single tap the function button to record rotation end position.



#### (4) Start auto rotation movements

The gimbal automatically restores to the start position, while the tilt axis and pan axis start rotating at a constant speed according to pre-set speed to end position, repeat step (2) (3) to start again.



Exit → Double tap Trigger button → Exit the auto-rotation mode and reset

## Connecting to Camera


G6 Plus gimbal can connect to the camera by Feiyu ON App.

### Operations available after connecting to the camera:

Button	Operation	Function
Setting Button	Single tap	Single tap in the main interface of the gimbal display can switch to the camera modes
Shutter Button	Single tap	On the main interface of the gimbal display, single tap for photo shooting / start shooting / stop shooting

### Steps of connecting to camera:

- (1) Turn on your sports camera's WiFi (2.4GHz)
- (2) Successively select "Settings" -- "Parameters Settings" -- "WiFi Settings" on Feiyu ON App
- (3) Select camera model
- (4) Select your camera connection name and enter the correct connection password of your camera
- (5) Waiting for connecting
- (6) Connect successfully

If icon  appears on the display screen, it means the gimbal failed to connect to the camera, try to restart gimbal or camera, or reconnect according to above steps.


If the WiFi is not connected for a long time, please restart the camera's WiFi.

## Firmware Upgrade

Connect the gimbal to the Feiyu ON App, to upgrade the firmware through the App.



Feiyu ON




## Gimbal Initialization

You can initialize your gimbal when:


- (1) When camera is not level
- (2) If not used for a long period of time
- (3) In case of extreme temperature variations

### Adjusting Steps




1

Tap the function button for 5 consecutive times and hear the "beep" sound, and the motor will stop working and "Initing" shows up.



2

Place the gimbal on the table unmoved, and the gimbal automatically detect whether or not it is placed on a static flat surface, and then its initializing will start automatically showing "Initing" on the display, and "Success" will be displayed after the initializing has been successfully completed.




3

After the initialization is done, single tap the function button to wake up and return to the main interface.

**NOTE:** If the initialization is not successful for a long time, long press the function button to turn off the gimbal, restart it and then initialize.

# 6. Specifications



## Specifications

Product Name	G6 Plus 3-Axis Stabilized Handheld Gimbal for Camera
Max. Tilting Range	260°
Max. Rolling Range	320°
Max. Panning Range	360°
Tilting Speed	2°/s ~ 75°/s
Panning Speed	3°/s ~ 150°/s
Operation Time	9 Hours
Weight	663g ( Not including the battery, camera, camera lens, etc. )
Payload	800g ( In center of gravity balanced state )
Compatible Cameras for Reference	Sony RX100 / Sony a6300 (16-50 or 28-70mm) / Sony a6500 (16-50 or 28-70mm) / Canon M10 (15-45mm) / Canon G3X , ect. Sony RX0 / GoPro HERO series sports cameras Fit for smartphone with smartphone adapter(Optional accessory)

## Guilin Feiyu Technology Incorporated Company

**Website:** [www.feiyu-tech.com](http://www.feiyu-tech.com)

**E-mail:** [service@feiyu-tech.com](mailto:service@feiyu-tech.com)

**Tel:** +86(0)773 2320865

Due to software and hardware improvements, your actual product might differ from the descriptions and pictures in this user manual. You can get the latest user manual from the official website.

For more information, please visit our official website



### DISCLAIMER

Prohibit any user for any illegal purpose. Users will be responsible for all behaviors of purchase and use products.

The Company assumes no liability for any risks related to or resulting from the debug and use of this product (including the direct, indirect or third-party losses).

For any unknown sources of using, we will not be at any services.

The updating and changes of product firmware and program may cause changes in function descriptions in this user manual, please read the instructions carefully before upgrading the firmware and use the corresponding user manual.

You can get the latest user manual from the official website: [www.feiyu-tech.com](http://www.feiyu-tech.com)

FeiyuTech reserves the right to amend this manual and the terms and conditions of use the gimbal at any time.