

MOZA Air 2 Camera Compatibility List											
Brand	Model	Select	Cable	Shutter	Record	ISO	TV	AV	Auto Focus	Focus Control	Power Supply
CANON	EOS R	M3C-USB	M3C-Micro+Micro to Type-C Adapter (optional)	✓	✓	✓	✓	✓	✓	✓	—
	EOS RP			✓	✓	✓	✓	✓	✓	✓	—
	EOS 6D Mark II			✓	✓	✓	✓	✓	✓	✓	—
	EOS 6D			✓	✓	✓	✓	✓	✓	✓	—
	EOS 60D			✓	✓	✓	✓	✓	✓	✓	—
	EOS 77D			✓	✓	✓	✓	✓	✓	✓	—
	EOS 80D			✓	✓	✓	✓	✓	✓	✓	—
	EOS 5D2			✓	✓	✓	✓	✓	✓	✓	—
	EOS 5D3			✓	✓	✓	✓	✓	✓	✓	—
	EOS 800D			✓	✓	—	✓	✓	✓	✓	—
	EOS 5D Mark IV		M3C-Mini	✓	✓	✓	✓	✓	✓	✓	—
	EOS 200D II			✓	✓	✓	✓	✓	✓	✓	—
	EOS M50			✓	✓	✓	✓	✓	✓	✓	—
	EOS M5	MCSC-C1	C1 Shutter Cable (optional)	✓	—	—	—	—	—	—	—
	EOS 750D			✓	—	—	—	—	—	—	—
SONY	Alpha 7S	M3C-USB	M3C-Micro	—	✓	✓	✓	✓	✓	—	✓
	Alpha 7R			—	✓	✓	✓	✓	✓	—	✓
	Alpha 6300			—	✓	✓	✓	✓	✓	—	✓
	Alpha 6400			—	✓	✓	✓	✓	✓	—	✓
	Alpha 6500			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7S II			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7R II			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7 II			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7 III			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7R III			—	✓	✓	✓	✓	✓	—	✓
	DSC-RX100M3			—	✓	✓	✓	✓	✓	—	✓
	DSC-RX100M4			—	✓	✓	✓	✓	✓	—	✓
	DSC-RX100M5			—	✓	✓	✓	✓	✓	—	✓
	Alpha 7S	MCSC-Multi	MCSC-Multi	✓	✓	—	—	—	✓	—	✓
	Alpha 7R			✓	✓	—	—	—	✓	—	✓
	Alpha 6300			✓	✓	—	—	—	✓	—	✓
	Alpha 6400			✓	✓	—	—	—	✓	—	✓
	Alpha 6500			✓	✓	—	—	—	✓	—	✓
	Alpha 7S II			✓	✓	—	—	—	✓	—	✓
Panasonic	Alpha 7R II	MCSC-Multi/C	MCSC-Multi/C	✓	✓	—	—	—	✓	—	✓
	Alpha 7 II			✓	✓	—	—	—	✓	—	✓
	Alpha 7 III			✓	✓	—	—	—	✓	—	✓
	Alpha 7R III			✓	✓	—	—	—	✓	—	✓
	DSC-RX100M3			✓	✓	—	—	—	✓	—	✓
	DSC-RX100M4			✓	✓	—	—	—	✓	—	✓
	DSC-RX100M5			✓	✓	—	—	—	✓	—	✓
	DMC-G7KGK	MCSC-Remote	MCSC-Remote	✓	✓	—	—	—	✓	—	—
	DMC-G85GK			✓	✓	—	—	—	✓	—	—
	DMC-GH3			✓	✓	—	—	—	✓	—	—
	Lumix GH4			✓	✓	—	—	—	✓	—	—
	DC-S1GK-K			✓	✓	—	—	—	—	—	—
Nikon	Z6	M3C-USB	M3C-Micro+Micro to Type-C Adapter (optional)	✓	✓	✓	✓	✓	✓	✓	—
	Z7			✓	✓	✓	✓	✓	✓	✓	—
	D850			✓	✓	✓	✓	✓	✓	✓	—
FUJIFILM	X-T2	MCSC-C1	C1 Shutter Cable (optional)	✓	✓	—	—	—	✓	—	—
	X-T3			✓	✓	—	—	—	✓	—	—
	X-T20			✓	✓	—	—	—	✓	—	—
	X-T30			✓	✓	—	—	—	✓	—	—